

SFX Switchbox- DMX protocol			
Version 1.2 F.G.			
Mode /Channels. 9	DMX Value	Function	Type of control
1	000-099	Safety (0=Default) Safe	step
	100-154	Armed	step
	155-255	Safe	step
2	000-179	Channel 1 (0=Default) Off	step
	180-255	On	step
3	000-179	Channel 2 (0=Default) Off	step
	180-255	On	step
4	000-179	Channel 3 (0=Default) Off	step
	180-255	On	step
5	000-179	Channel 4 (0=Default) Off	step
	180-255	On	step
6	000-179	Channel 5 (0=Default) Off	step
	180-255	On	step
7	000-179	Channel 6 (0=Default) Off	step
	180-255	On	step
8	000-179	Channel 7 (0=Default) Off	step
	180-255	On	step
9	000-179	Channel 8 (0=Default) Off	step
	180-255	On	step