

5Master- DMX protocol			
Version 1.10 F.G.			
Mode /Channels. 6	DMX Value	Function	Type of control
1	000-099	Fire Safety (0=Default) Safe	step
	100-154	Armed	step
	155-255	Safe	step
2	000-179	Fire1 (0=Default) <i>Fire 1 to 5 = Display Right to Left</i> Off	step
	180-255	On	step
3	000-179	Fire2 (0=Default) <i>Fire 1 to 5 = Display Right to Left</i> Off	step
	180-255	On	step
4	000-179	Fire3 (0=Default) <i>Fire 1 to 5 = Display Right to Left</i> Off	step
	180-255	On	step
5	000-179	Fire4 (0=Default) <i>Fire 1 to 5 = Display Right to Left</i> Off	step
	180-255	On	step
6	000-179	Fire5 (0=Default) <i>Fire 1 to 5 = Display Right to Left</i> Off	step
	180-255	On	step